

LG POWER

User manual

Gaming 998B – Rambot



Thank you for purchasing this case from LC-Power.

Please read this manual before usage.

Specifications may be subject to change without prior notice.


1. Specification

Size	523 x 224 x 488 mm (h x w x d)
M/B	ATX / micro ATX / mini ITX
HDD	5x 3.5" HDD; 2x 2.5" HDD/SSD
PSU	ATX
Fans	Front: 3x 120 mm Top: 2x 120/140 mm Inside: 1x 120 mm Back: 1x 120 mm
Water cooling (if no fans are mounted)	Front: 360 mm Top: 240 mm Rear: 120 mm
Expansion Slots	7 (screwable)
Screw bags	Cable tie 80mm: 5pcs MB Stand off 6# 5H 8*4.5L====>10pcs M3*5====>6pcs(2.5"HDD*6) Black screws for side panel M4*5====>8pcs M5*10 TP3====>16pcs(FAN*16)

	6#*4===>27pcs(MB*10,3.5"HDD*13,Power*4)
--	---

2. Installation

2-1 Controller board



Connect the fan cables to the controller board on the back side of the mainboard tray.
Connect the PATA/Molex connector to your power supply.

2-2 Front case fan installation



Fix the fans with screws to the case chassis.

2-3 3.5" HDD installation

Press the HDD into the bracket to fix it



2-4 Fan installation on the back side of the HDD bracket



2-5.2 Mainboard installation with stand-off am screws



#Additional 3x 3.5" HDD on MB tray


Additional 2x 2.5" HDD/SSD on the back side of the MB tray

2-6 Tempered glasses side panel installation

Align 4 screw holes to washer and fasten screws



Front I/O Connector



The product has a two year warranty period from the date of purchase, service issues will be handled by your dealer.

If the case is damaged due to improper operation, the warranty period expires immediately.

Check www.lc-power.com or contact us by e-mail at support@lc-power.com.

Silent Power Electronics GmbH,

Formerweg 8,

47877 Willich,

Germany

