

LC-POWER

Installation guide
Installationsanleitung

- LC-CC-120-LiCo
- LC-CC-240-LiCo
- LC-CC-360-LiCo

Liquid Cooling (CPU)
Flüssigkühlung (CPU)

Silent Power Electronics GmbH, Fornerweg 8
47877 Willich, Germany, www.lc-power.com

1 INTEL / AMD
120

2 INTEL / AMD
120

3 INTEL / AMD
240

4 AMD
AMD Socket
AM4/AM3(+)/AM2(+)/FM2(+)/FM1

5 AMD
AMD Socket
AM4/AM3(+)/AM2(+)/FM2(+)/FM1

6 AMD
AMD Socket
AM4/AM3(+)/AM2(+)/FM2(+)/FM1

7 AMD
AMD Socket
AM4/AM3(+)/AM2(+)/FM2(+)/FM1

8 AMD
3 pin: Pump power connection
4 pin: Fan power connection
3-Pin: Stromversorgung Pumpe
4-Pin: Stromversorgung Lüfter

A 120 x4
240 x8
360 x12

B x4

C x4

D x4

E 120 x4
240 x8
360 x12

F x1

G x4

H x4

J x2

L A B

M 120 x4
240 x8
360 x12

K x2

4 INTEL
1700/1200/115x/1366/775

5 INTEL
Intel Socket LGA
1700/1200/115x/1366/775

6 INTEL
Intel Socket LGA
1700/1200/115x/1366/775

7 INTEL
Intel Socket LGA
1700/1200/115x/1366/775

8 INTEL
Intel Socket LGA
2011/2011-3/2066

9 INTEL
Intel Socket LGA
2011/2011-3/2066

10 INTEL
Intel Socket LGA
2011/2011-3/2066

11 INTEL
3 pin: Pump power connection
4 pin: Fan power connection
3-Pin: Stromversorgung Pumpe
4-Pin: Stromversorgung Lüfter