

### User Manual USB 3.0 enclosure for a SATA HDD (8,89cm/3,5")



Silent Power Electronics GmbH  
Formerweg 8  
47877 Willlich  
Germany  
support@lc-power.com  
www.lc-power.com

Thank you for purchasing a hard disk drive enclosure from LC-Power. Please read the manual before usage. Specifications may be subject to change without prior notice.

#### 1. Specifications

##### Hard disk drive enclosure for a 8,89cm/3,5" SATA HDD

- USB 3.0, downwardly compatible to USB 2.0 and USB 1.1
- For a 8,89cm/3,5" SATA hard disk drive up to 4TB
- Chipset for SATA 6Gb/s (for SATA I/II/III)
- LED status indicator
- Plug'n'Play

##### Nominal data transfer rate:

- Superspeed up to 5Gb/s (USB 3.0)
- Highspeed up to 480Mb/s (USB 2.0)
- Fullspeed up to 12Mb/s (USB 1.1)

##### System compatibility:


Windows XP/Vista/7/8, Mac OS 9.2, Linux 2.4.2 or higher

##### Included in delivery:

Enclosure, USB 3.0 cable, external power supply, stand, mounting material and manual


#### 2. Installation

##### Step 1:



Unscrew both screws on the side of the enclosure and remove the HDD rack.

##### Step 2:



Connect the 8,89cm/3,5" SATA hard disk drive with the matching connector of the PCB interface. Fix the hard disk drive to the HDD rack.

##### Step 3:



Move the HDD rack and the hard disk drive into the enclosure and fix it with the screws to the enclosure.

(Hard disk drive not included in delivery)

#### 3. Notes

Avoid direct sunlight and a high temperature environment, keep the enclosure far away from fire and heat sources.

Keep it in dry places, keep it away from corrosiveness causing materials.

We recommend that parents should guide their children using the item, strictly following the notes in this manual.

#### 4. Service

The product has a two year warranty period from the date of purchase, service issues will be handled by your dealer.

If the enclosure is damaged due to improper operation, the warranty period expires immediately.

Check [www.lc-power.com](http://www.lc-power.com) or contact us by e-mail at [support@lc-power.com](mailto:support@lc-power.com).